


# MICKEY'S CIRCUS


## OPERATING INSTRUCTIONS

1. Tighten all bulbs into their sockets to insure a proper electrical connection before the first use.
2. Musical is operated with (Transformer-AC220/240V-Output-DC9V/100/1000MA) which is included in the box.
3. Plug the transformer into the adaptor jack opening located at the back of the platform and connect it to a household electrical outlet.
4. The operating switch is located at the back side near the adaptor jack opening.
  - Push the switch to the left to turn off the musical.
  - Move the switch to the right to turn on the light, movement and music.



## REPLACING THE BULBS

1. There are 16 light bulbs at the front view and 4 light bulbs at the ceiling of the circus. All of them are replaceable.
2. To replace the light bulbs, unscrews the bulb in a counter clockwise direction.
3. Reverse the procedure after replacing or tightening the bulbs.



Bulbs unscrew in a counter clockwise direction